

## Note:

Contact DNRC if you have any questions or if the mapped information appears incorrect.

The points of diversion (PODs) and places of use (POUs) are derived from water right legal land descriptions. PODs are placed at the center of their legal land description, not at their true geographic location. POUs are drawn as polygons of the entire legal land description.

